




FSCUT4000 Laser Cutting System User Manual



Shanghai Friendess Co., Ltd
www.fscut.com
Ver. 2.0



Thank you for choosing our products!

This manual gives a detailed introduction to the usage of FSCUT4000 laser cutting controller, including technical features and installation instructions etc. For CypCut laser cutting software operation, please refer to the CypCut user manual. For other matters you can contact us directly.

Operating personnel should read the manual in detail which will be helpful for a better use of the product.

Due to the continuous updating of product functions, the products you receive may differ from the statement in this manual in some respects. We apologize for any inconvenience it may cause.



Content

1.	Product Description	6
1.1	Brief Introduction	6
1.2	Connection Diagram	6
1.3	Technical Reference	7
1.4	Control Card Installation	8
1.4.1	Install steps.....	8
1.4.2	Troubleshoot.....	9
2.	BCL3724 Wiring Instruction	11
2.1	BCL3724 Description	11
2.2	Signal Type	12
2.2.1	Input signal.....	12
2.2.2	Relay output	14
2.2.3	Thyristor output	14
2.2.4	Analog output.....	15
2.2.5	PWM output	15
2.3	I/O Specification.....	15
2.3.1	External power supply	15
2.3.2	Servo control port	15
2.3.3	Servo drive control signal	17
2.3.4	Origin and limit.....	24
2.3.5	Common input	24
2.3.6	Common output	24
2.3.7	Analog output.....	25
2.3.8	PWM output	25
2.4	Wiring Diagram.....	26
2.5	Laser Wiring Diagram.....	27
2.5.1	YAG laser	27
2.5.2	CO2 laser.....	27
2.5.3	IPG-YLR	28
2.5.4	IPG_ YLS Germany	29
2.5.5	IPG_ YLS American.....	30
2.5.6	SPI-500W-R4	31
2.5.7	FEIBO MARS.....	32
2.5.8	JK/GSI-FL.....	33
2.5.9	Rofin	34
2.5.10	Raycus	35
2.5.11	Max	36
3.	Machine Config Tool.....	37
3.1	Installation and Operation.....	37
3.2	Password	37
3.3	User Interface	38
3.4	Mechanism Config	39



3.5	Return Origin Config	42
3.6	Laser Configuration	43
3.6.1	CO2 laser configuration	43
3.6.2	IPG laser configuration	44
3.6.3	Feibo/Rofin/SPI/GSI/JK laser configuration	45
3.6.4	Configuration of other laser type	46
3.7	BCS100 Configuration.....	46
3.7.1	Use BCS100 as height control unit.....	46
3.7.2	Use external device as height control unit	47
3.8	Gas System	48
3.9	Alarm Configuration	48
3.9.1	Warning message	49
3.9.2	Emergency stop button	49
3.9.3	Safety mode.....	49
3.9.4	Custom alarm	49
3.9.5	Allowed dual-drive error.....	49
3.10	Common input	50
3.11	Common output	51
3.11.1	Output configuration.....	51
3.11.2	Auto lubricate.....	51
3.11.3	Custom output	52
3.11.4	Regional output.....	52
3.12	Find Edge Setting	52
3.13	BCP5045 Panel.....	53
4.	Electrical System Adjustment	54
4.1	Power Supply Checking.....	54
4.2	Basic Machine Motion Config Checking	54
4.3	Hardware Signal Checking	56
4.4	Basic Motion Test.....	57
4.5	CypCut Basic Function Test	57
4.6	Position-Loop PID Self Adjustment.....	57
5.	Adjustment Steps	59
6.	Common Problems in Close-Loop control	60
6.1	Motor Runaway Error	60
6.2	Encoder and Speed Check Failed.....	60
6.3	Position Error Too Large.....	60
7.	Optimize Machine Motion Performance	62
7.1	Calculate Inertia Ratio and Preview Machine Performance Features.....	62
7.2	Motion Control Parameter Adjustment	63
7.2.1	Motion control parameter description	63
7.2.2	Adjust cutting acceleration.....	63
7.2.3	Adjust travel acceleration.....	64
7.2.4	Adjust low pass filter frequency	64
7.2.5	Curve precision and corner precision	65



8.	FAQ.....	66
8.1	Cutting is Slow or Jamming	66
8.2	Corner Over Burned	66
8.3	Laser No Emission	66
9.	Appendix	68
9.1	Fly Cut Operation Guide.....	68
9.1.1	Function.....	68
9.1.2	Function description	68
9.2	Pitch Error Compensation.....	69
9.2.1	Pitch error compensation description	69
9.2.2	Mechanical origin	69
9.2.3	Measure pulse equivalent	69
9.2.4	Mechanic error measure	70
9.2.5	Import measurement data to CypCut.....	71
9.2.6	The operation steps of pitch error compensation	72
9.2.7	FAQ.....	73



1. Product Description

1.1 Brief Introduction

FSCUT4000 is a high performance laser cutting system of close-loop control developed by Shanghai Friendess Company. It is widely used in metal and non-metal laser cutting application, has gained wide popularity among users at home and abroad.


This manual served as installation and operation guide for FSCUT4000 system.

FSCUT4000 system hardware table:

Item	Model	Qty.
Motion control card	BMC1214	1 pcs
I/O terminal board	BCL3724	1 pcs
62-pin cable (2m)	C62-2	1 pcs
Servo cable (1.5m)	C15-1.5	4 pcs
Control software	CypCut	1 pcs
Wireless handheld remote	WKB	1 pcs
NC panel (optional)	BCP5045	1 pcs

1.2 Connection Diagram

BMC1214 card adopts PCI interface. Dimension: 155mm*106mm. The socket (DB62M) on control card connects with BCL3724 I/O terminal by C62-2 cable. Wiring diagram shown below:




1.3 Technical Reference

Motion Control	Motor control signal	Analog output of 4 servo axis ports, -10V—+10V.
		Encoder feedback channel of 4 servo axis ports, 10MHz.
		Dedicated signal inputs of origin, positive/negative limit and servo alarm for each axis.
		Dedicated signal outputs of servo enable and alarm reset etc., for each axis.
	Motion control performance	Control cycle 1ms.
		S-type acceleration and deceleration with filter.
Velocity look-ahead strategy, intelligent speed control at turning point.		
Laser control signal	Local curvature analysis and speed restriction at curves.	
	Auto smooth corner.	
	1 PWM signal, DIP switch(24V/5V as options)	
I/O function	3 analog output ports of 0~10V	
	1 analog input port of 0~10V	
	12 common input ports.	
Work environment	20 output: 6 relay outputs and 14 thyristor outputs.	
	Temperature: 0-55 Celsius degree	
Power supply	Humidity: 5% ~ 90% no condensation	
	24V, 2A	




1.4 Control Card Installation


1.4.1 Install steps

 Caution	Please wear anti-static gloves to prevent possible electrostatic damage to the motion control card.
--	--

- (1) Power off computer, insert the control card into PCI socket, and fix the control card tightly;
- (2) After start up computer, "Add Hardware Wizard" pops out and click "Cancel" button, as shown below. If this dialog box does not appear, indicating the card is in poor connection, please repeat the first step.





- (3) Install CypCut software. The driver program will be installed by default option automatically.
- (4) Open windows device manager to confirm installation succeed. Below image shows the installation is succeed.







1.4.2 Troubleshoot

- (1) If "Find New Hardware" dialog box does not pop out after start up computer or control card does not shown in device manager, indicating that the control card is not in good connection with PCI socket. Please replace the PCI socket or change another computer, insert the control card tightly and reinstall software.
- (2) If the device has a yellow exclamation mark, double-click  to open its attributes page, and select "Detail Information" as shown below:



- (3) If the first half of the 'device instance ID' attribute is displayed as  it means computer has correctly recognized the motion control card but software installation might be failed. Try install CypCut again, if installation still fails, please contact our technical support.
- (4) If the first half of 'device instance ID' attribute is not , it



indicates computer doesn't recognize the control card. Power off computer and change PCI socket, install the card firmly and repeat installation again.

- (5) If step (4) still fails, the control card might be damaged please contact our technicians.



You can either use guide rail or fixed installation to install BCL3724 board, product dimension 315mm*107mm. DB62M socket connected with JP1 interface of BMC1214 card by C62-2 cable.

4 sockets (DB15M) on top left are for servo control, from left to right is X, Y1, Y2 and W axis port.

The signal terminals on bottom left are positive/negative limit, origin inputs of X, Y and W axes. All lower terminals are conducted, ground end of COM, 0V.

On bottom right are 20 common output terminals which are thyristor emitter output. Thyristor output is 24V, common cathode.

Above are PWM signal and 4 DA analog signal terminals.

There is a DIP switch down below PWM:

Switch P1 and P2 to set PWM voltage


P1	P2	Description
On	Off	PWM voltage is 24V
Off	On	PWM voltage is 5V

2.2 Signal Type


2.2.1 Input signal

The input signals: positive/negative limit, origin, common input. All input terminals of BMC1214 are low-level active, support NO (normally-open) and NC (normally-close) input. When set input as normally-open, input signal active when conduct with 0V; when set input as normally-close, input signal active when disconnect with 0V.


The polarity of input can be changed by jump-wire, IN10, IN11, IN12 support jump-wire. There are 2 status of jump-wire, ACT_LOW means low-level active (input 0V active); ACT_HIGH means high-level active (input 24V active). The default state is ACT_LOW.




The typical wiring of photo-electric switch shown below, must use NPN 24V type switch.



The typical wiring of contact switch shown below.



The typical wiring of magnetic switch shown below, must use NPN 24V type switch.






2.2.2 Relay output


There are 6 relay output on BCL3724 terminal board which are OUT1-OUT6. OUT1-OUT4 only support normally open, OUT5-OUT6 have both NO and NC options. The maximum load of relay: DC 30V, 8A; AC 250V, 8A. Recommend to use load under 2A, the inductive load or high power load will reduce the service time of relay switch.

Wiring between relay output and contact shown below:



2.2.3 Thyristor output

There are 14 thyristor output on BCL3724 from OUT7-OUT20, which can drive 24V DC device directly, drive capacity is 500mA. Wiring diagram shown below:






2.2.4 Analog output

3 analog output of 0-10V.

Output range	0V~+10V
Maximum output load	50mA
Maximum capacitive load	350pF
Input impedance	100K Ω
Maximum bipolar error	+/-50mV
Resolution	10mV
Conversion speed	400us

2.2.5 PWM output

There is one PWM port on BCL3724 for laser average power modulation. There are 5V and 24V for options. The duty cycle is adjustable from 0%~100%, the highest carrier frequency 50 KHz. The signal output shown below:



Set PWM signal level, 5V or 24V set by DIP switch.

2.3 I/O Specification

2.3.1 External power supply


BCL3724 requires external 24V DC power supply. The 24V and COM connect with 24V and 0V of power supply.

2.3.2 Servo control port

The 4 servo ports on BCL3724 are DB15 sockets, signal pin description listed



below:



The signal pin description of C15-1.5 cable listed below:

15-pin servo control interface			
Pin	Description	Pin	Description
1	DA (-10~10V analog)	9	AGND (analog ground)
2	OS (zero speed clamp)	10	0V (power supply ground)
3	A+ (encoder A phase positive)	11	A- (encoder A phase negative)
4	B+ (encoder B phase positive)	12	B- (encoder B phase negative)
5	Z+ (encoder Z phase positive)	13	Z- (encoder Z phase negative)
6	SON (servo enable)	14	ALM (alarm signal)
7	CLR (alarm clear)	15	0V (power supply ground)
8	24V (power supply)		

+24V, 0V: give 24V DC power supply to servo driver;

SON: servo-on output;

ALM: alarm input from servo;


DA, AGND: analog output for motor control;

CLR: alarm reset;

OS: zero speed clamp signal;

A+ 、 A- 、 B+ 、 B- 、 Z+ 、 Z-: Encoder 3-phase input signal, to check encoder zero point.

The polarity of SON and ALM can be changed by jump-wire;



SON signal jump wire to ACT_LOW, output is low-level active (output 0V active);
Jump wire to ACT_HIGH, output is high-level active (output 24V active); Default is ACT_LOW.



ALM signal jump wire to ACT_LOW, input is low-level active (input 0V active); Jump wire to ACT_HIGH, input is high-level active (input 24V active); Default is ACT_LOW.

2.3.3 Servo drive control signal

The wiring diagram with Panasonic, Yaskawa, Sanyo and Schneider provided here. For servo driver parameter setting you can take reference from ServoTools calculation. If you have any question please contact our technical support.

For other brand servo wiring please take notice of following items:


- (1) Make sure the servo supports velocity control mode. For example, Panasonic A5 series servo must choose full-function type, cannot use pulse type;
- (2) Check if SON signal is low-level active (SON is active when conducted with GND of 24V);
- (3) Check if there is external emergency stop in servo I/O;
- (4) Before trial run of driver, provide 24V power supply to IO terminal board, the 24V power supply provided by BCL I/O board;
- (5) If driver still can't run, check if the parameter 'positive/negative direction drive inhibit' in driver is disabled.



Panasonic servo wiring diagram

FSCUT DB15 servo control

MINAS-A 50P



Panasonic A5 reference setting


Parameter	Description	Recommended value
Pr0.01	Control mode	1
Pr0.02	Real time auto tuning	0
Pr0.04	Inertia ratio	You can calculate the inertia ratio by Panasonic servo software
Pr0.11	Encoder output pulse per motor revolution	Set by mechanism feature, the pulse equivalent should be among 1000-2000. For example, if the linear distance is 10mm on machine load per motor rotation, the pulse per revolution should be 10000, and Pr0.11 set 2500.
Pr1.01	1st gain of velocity loop	75.0Hz
Pr1.02	1st time constant of velocity loop integration	9.0ms
Pr1.04	1st time constant of torque filter	0.3ms
Pr3.02	Input gain of speed command	Set by maximum motor speed. If maximum motor speed is 4000rpm, set 400 here.



Pn401	Torque command filter time constant	0.30 MS
Pn50A	Input signal	8100
Pn50B	Input signal	6548



Sanyo R series wiring diagram



Sanyo R2 reference setting

Parameter	Description	Recommended value
SY09	Control mode	01
Gr0.00	TUNMODE, tuning mode selection.	02
Gr1.12	KVP, velocity loop proportional gain	75H z
Gr1.13	TVI, velocity loop integral time constant	9ms
Gr1.14	Inertia ratio	Input the value calculated by Sanyo servo software, you can also calculate by Friendess ServoTools.
Gr8.29	VCGN, analog velocity command gain	Set by the maximum motor rpm. For example, if the maximum motor speed is 4000rpm, set this parameter as 4000.
G r9.00	F-OT, forward over travel	00
Gr9.01	R-OT, reverse over travel	00
G r9.27	VLPCON, velocity loop	00
G rB.13	Hold brake delay	00




G rB.14	Release brake delay	00
G rC.04	Differential pulse output	Set by mechanism feature, the pulse equivalent should be among 1000-2000. For example, if the linear distance on machine load is 10mm per motor rotation, the pulse per revolution should be 10000, and Pr0.11 set 2500.



Schneider Lexium 23D wiring diagram

FSCUT DB15 servo control

Schneider Lexium 23D



Schneider 23D reference setting

Parameter	Description	Recommended value
P1-01	Control mode	0002
P1-37	Inertia ratio	Input inertia ratio calculated by Schneider servo software, you can also use Friendess ServoTools to calculate the inertia ratio.
P1-40	VCM, maximum command rotation speed	Set by maximum RPM of motor. For example, if the maximum RPM of motor is 4000rpm, set same value for this parameter.
P1-46	ENCOUTRES, encoder output pulse per motor revolution	Set by mechanism feature, the pulse equivalent should be among 1000-2000. For example, if the linear distance is 10mm per motor rotation, the pulse per revolution should be 10000, and Pr0.11 set 2500.
P2-04	KVP, velocity control gain	565rad/s
P2-06	KVI, velocity integral compensation	108rad/s



P 2-32	ATMODE, automatic adjustment	0
--------	------------------------------	---

2.3.4 Origin and limit

X-: negative limit of X axis, dedicated input, low-level active;

XO: origin of X axis, dedicated input, low-level active;

X+: positive limit of X axis, dedicated input, low-level active;

COM: ground, the common end of above three signal ports.

Y1-: negative limit of Y1 axis, dedicated input, low-level active;

Y1O: origin of Y1 axis, dedicated input, low-level active;

Y1+: positive limit of Y1 axis, dedicated input, low-level active;

COM: ground, the common end of above three signal ports.

Y2-: negative limit of Y2 axis, dedicated input, low-level active;

Y2O: origin of Y2 axis, dedicated input, low-level active;

Y2+: positive limit of Y2 axis, dedicated input, low-level active;

COM: ground, the common end of above three signal ports.

W-: negative limit of W axis, dedicated input, low-level active;

WO: origin of W axis, dedicated input, low-level active;

W+: positive limit of W axis, dedicated input, low-level active;

COM: ground, the common end of above three signal ports.

You can change input polarity of origin and limit signals via machine config tool.

See details in chapter 3 machine config.

2.3.5 Common input

There are 12 common input IN1-IN12. You can assign common inputs as user-defined software button or alarm input. See details in chapter 3 machine config.

2.3.6 Common output

There are 20 common output OUT1-OUT20. Common output can be assigned as user-defined signal output for laser, gas, indicator lamp controlling etc. See details in chapter 3 machine config.



2.3.7 Analog output


3 channels analog output of 0-10V, DA1, DA2 and DA3. Analog output can be assigned for laser peak power and gas valve control.

2.3.8 PWM output

For fiber laser configuration in CypCut machine config, PWM will be activated automatically for laser average power regulation. For other type laser, there is no signal output from PWM port.



2.4 Wiring Diagram






2.5 Laser Wiring Diagram

2.5.1 YAG laser

Assign an output for laser emission and connect with laser.

2.5.2 CO2 laser

Here take example of NT-3200SM CO2 laser.




Note:

Some of CO2 laser also supports PWM control mode, wiring can take reference from Max laser.



2.5.3 IPG-YLR



It's recommended to use serial communication (RS232) or network communication under serial or Ethernet communication, CypCut can monitor laser status in real time and control laser of emission, aiming, peak power without DA analog output.

Recommend to use network communication for IPG-YLR series.


Note:

1. Remote start-up button is not necessary and not recommended for it might cause laser malfunction when laser is not well grounded.

2. Select 24V for PWM (DIP switch: PIN1 ON, PIN2 OFF).



2.5.4 IPG_YLS Germany




Note:

1. B2 'Emission ON' in XP1 interface is not necessary for CypCut, set 'Emission Status' as '0' in machine config, CypCut will not check laser emission status.
2. Select 24V for PWM (DIP switch: PIN1 ON, PIN2 OFF).



2.5.5 IPG_YLS American




Note:

1. B2 'Emission ON' in XP1 interface is not necessary for CypCut, set 'Emission Status' as '0' in machine config, CypCut will not check laser emission status.
2. Select 24V for PWM (DIP switch: PIN1 ON, PIN2 OFF).



2.5.6 SPI-500W-R4



Note:


1. When use MODINPUTTTL for laser modulation, select 5V for PWM (DIP switch: PIN1 OFF, PIN2 ON).
2. When use PIN1 of I/O interface for laser modulation, select 24V for PWM (DIP switch: PIN1 ON, PIN2 OFF).



2.5.7 FEIBO MARS


Computer RS232 DB9

FEIBO MARS-500W Laser System



BCL3724_V2.0 I/O Board

D-SUB 15




Note:

Select 24V for PWM (DIP switch: PIN1 ON, PIN2 OFF).



2.5.8 JK/GSI-FL




Note:

1. The interlock in SK11 interface
2. When use SK101 as modulation, select 5V for PWM (DIP switch: PIN1 OFF, PIN2 ON).
3. When use Pin-16 in PL5 as modulation, select 24V for PWM (DIP switch: PIN1 ON, PIN2 OFF).



2.5.9 Rofin




Note:

1. Take related reference for wiring of interlock in X720;
2. Select 5V for PWM ((DIP switch: PIN1 OFF, PIN2 ON; one of PIN3 or PIN4 ON and the other OFF).



2.5.10 Raycus



Note:


1. Raycus's latest products use 24V PWM, the old versions use 5V PWM. For latest Raycus laser, key switch turns to REM under serial communication, while for old versions key switch turns to ON position under serial communication. Laser PWM port will indicate its 24V or 5V control. No specific description indicates 5V PWM control.

2. 5V PWM control (DIP switch: PIN1 OFF, PIN2 ON).

3. 24V PWM control (DIP switch: PIN1 ON, PIN2 OFF).



2.5.11 Max

**Note:**


1. PD+/PD-(laser alarm output) connect to any input port in BCL3724 I/O board, then in 'machine config>alarm>custom alarm' setup the laser alarm (normally-open);
2. The ground end of aiming laser and laser emission can connect to any COM port in BCL3724 board.
3. 24V PWM control (DIP switch: PIN1 ON, PIN2 OFF; one of PIN3 and PIN4 is ON, the other is OFF).



3. Machine Config Tool


3.1 Installation and Operation

CypCut default installation contains machine config program.

In Windows Start > All Programs > CypCut open machine config program . 'CypCut laser cutting system' is software name which might be different of OEM version.

3.2 Password

You have to input password to start config tool.




Initial password 61259023.

Note:

All settings in machine config must setup by actual mechanism structure. Wrong settings will cause severe unknown problem! In machine config, all input are yellow color, and all output are green color.



3.3 User Interface



The first page open machine config is machine config overview. Click tab in top and left bar will open each parameter setup page for different machine module. For example, above three are entrance for laser, height control and gas system setting page. Click 'file location' will locate to folder of config data.

Click button in overview page will also open the parameter setting page of each module. Click 'Machine tool' will enter 'Machine' page.


Click 'import' to finish machine config setting by existing file. Click 'save' save the setting.

Note:

1. Data folder contains all config files of CypCut.
2. Data backup is in CypCut > File > Backup.



3.4 Mechanism Config



Config mechanism structure, single drive Y axis or dual-drive Y axis, also config rotary axis.

X axis range: the maximum travel range under software limit protection function, also the width of white frame in CypCut drawing board.

Y axis range: the maximum travel range under software limit protection function, also the length of white frame in CypCut drawing board.

Pulse equivalent: pulse output per 1 mm linear distance on machine load. You can calculate by ServoTools.

Servo alarm: set the triggered polarity of alarm signal is normally open or close.

Max speed: maximum user speed and acceleration restricted by CypCut.


Pitch compensation: compensation method for mechanic error including backlash



and offset error data from interferometer.


Squareness: this is to offset the error when X and Y mechanic is not orthogonal.

X/Y check: used for motor runaway risk checking.



Motor runaway check: to check if the motor rotation direction same with encoder feedback. For example: send voltage+ for motor rotation+. If encoder feedback pulses increase in positive value, it indicates motor rotation polarity same with encoder feedback. Otherwise, it cannot create a close loop control when motor rotation polarity different with encoder feedback, under this situation motor will never reach the target position and controller keep sending command signal, machine load will rush out, this scenario called 'motor runaway'. (Note: if doesn't pass motor runaway test, cannot open CypCut for machine spindle adjust).

The sequence of motor runaway check:



Close-loop jog: check the option and jog X axis, observe the motor rotation and encoder feedback polarity.

Open-loop jog: check the option controller only send analog output, doesn't compare with feedback. Dual-drive axis doesn't recommend this function.

Reverse X: if machine load direction not same with jog direction, click

to reverse it and doesn't need to change setting in servo driver.

Pulse check: check if encoder feedback pulses match with controller command.



3.5 Return Origin Config

MachineOriginLaserFollowerGasFocusAlarmsIOListInportOutputExtendIOBCP5045

Return Origin

Enable soft limit Prompt user at start Return origin alarm

X origin directi: Neg Pos Y origin directi: Neg Pos

Origin signal: ORG Limit Limit logic:

Z-Phase signal: Enable

High Speed: X rollback :

Low Speed: Y rollback :

Return ORG using origin signal(Use Z signal)

The diagram illustrates the return to origin process. It shows a horizontal axis with an 'origin' point. A blue arrow labeled 'Coarse positioning' points from the right towards the origin. A green arrow labeled 'Fine positioning' points from the origin to the left. A red arrow labeled 'Back distance' points from the origin to the right. A red arrow labeled 'moderating process' points from the origin to the left. A vertical line labeled 'Z signal' is positioned to the right of the origin.

Enable soft limit: check this option, software limit function will force start all the time.

Prompt user at start: prompt message when open CypCut to inform user execute return origin operation.

Origin direction: select return origin direction needed. Return origin direction decides which coordinate quadrant system runs with. For example, return origin direction of X and Y are both in negative direction, system runs in first quadrant coordinate.

Origin signal: FSCUT4000 must use origin switch, cannot take limit as origin.

ORG measure: measure the installation distance between limit and origin switch.

Z-phase signal: whether or not capture Z-phase signal results different return



origin process. The return origin process of each mode will display in picture. Dual-drive gantry synchronize function only available when capture Z-phase signal return origin.

Low speed: fine positioning speed, recommend to set 10mm/s.

High speed: course positioning speed, recommend to set 50mm/s.

Rollback: the distance motor rolls back after reach origin switch.

Limit logic: the polarity of limit and origin signal active.

3.6 Laser Configuration

CypCut programmed standard configuration for YAG, CO2, IPG, Raycus, SPI and many other brand laser, select laser type and there are different parameter settings under each page.

3.6.1 CO2 laser configuration

Laser

Laser type:

<input checked="" type="radio"/> CO2	<input type="radio"/> IPG	<input type="radio"/> Max	<input type="radio"/> Valley Nuo	<input type="radio"/> LianPing
<input type="radio"/> SPI	<input type="radio"/> CAS	<input type="radio"/> Raycus	<input type="radio"/> Rofin	<input type="radio"/> Others
<input type="radio"/> Mars	<input type="radio"/> EO	<input type="radio"/> Trumpf	<input type="radio"/> nLight	

Laser Power:

CO2 Configuration

Mechanical shutter: <input type="text" value="11"/>	Response input: <input type="text" value="0"/>
Electronic Shutter: <input type="text" value="1"/>	
Laser Model 1: <input type="text" value="13"/>	Laser Model 2: <input type="text" value="14"/>
DA Select: <input type="text" value="None"/>	
DA Range: <input type="radio"/> 0~5V <input checked="" type="radio"/> 0~10V	
Minimum Power: <input type="text" value="1%"/>	

Mechanic shutter: the output for mechanic shutter.

Digital shutter: the output for digital shutter.

Response input: response input when open mechanic shutter.



Laser form: laser form can be set as continuous wave, gate pulse and high power pulse by mode 1 and mode 2 output.

DA port: there are three DA analog output, select one of them for laser power control.

DA range: set the analog voltage range.

Minimum power: the minimum laser power.

3.6.2 IPG laser configuration

PWM enable: select a relay output in BCL3724 board as switch of PWM signal. Relay output can avoid laser leakage.

DA output: there are 3 DA ports of analog output, select one of them for laser power control. When use RS232 or network control doesn't require DA port.

IPG Fiber Laser Configuration:

Remote start button:

When key switch turns to remote control mode, you can startup laser by remote



button. If use remote start button, you need to setup the output port for the button. (Remote start up button is not recommended, for it's easy to cause laser malfunction).

IPG remote control:

When use IPG remote control, CypCut will monitor laser status in real time, then communicate and control laser emission, guide beam and peak current etc. When use remote control mode, doesn't require DA analog port.

IPG remote control supports serial and network communication, user can set IP or COM port as needed. When laser and BCS100 both select network communication with PC, take notice that the network segment of each IP cannot be same. For example, IP segment of BCS100 is 10.1.1.x while laser IP set 192.168.1.x. Recommend to use network communication which is more stable. If use serial communication, the shielding layer and outer shell of the connected device must be well grounded.

3.6.3 Feibo/Rofin/SPI/GSI/JK laser configuration

Laser

Laser type:

<input type="radio"/> CO2	<input type="radio"/> IPG	<input type="radio"/> Max	<input type="radio"/> Valley Nuo	<input type="radio"/> LianPing
<input type="radio"/> SPI	<input type="radio"/> CAS	<input type="radio"/> Raycus	<input type="radio"/> Rofin	<input type="radio"/> Others
<input checked="" type="radio"/> Mars	<input type="radio"/> EO	<input type="radio"/> Trumpf	<input type="radio"/> nLight	

Laser Power:

PWM Enable + PWM Enable - Shutter Enable

DA Select:

DA Range: 0~5V 0~10V

COM Debug mode

Feibo, Raycus and SPI laser are similar with IPG laser configuration, and support serial communication.

Debug mode: when enable this mode, CypCut log window will display the communication code with laser.



3.6.4 Configuration of other laser type

Laser

Laser type:

CO2 IPG Max Valley Nuo LianPing
 SPI CAS Raycus Rofin Others
 Mars EO Trumpf nLight

Laser Power:

PWM Enable + PWM Enable - Shutter Enable
DA Select: Shutter Ready
DA Range: 0~5V 0~10V Delay:

Shutter enable: output to open laser shutter.

3.7 BCS100 Configuration

3.7.1 Use BCS100 as height control unit

Follower

BCS100 BCS100 Demo IO

Network Config:

IP address:

This computer installed 1 netcards:
Network Card Name: 本地连接
MAC : 34-97-F6-D9-0B-C5
IP : 10.1.255.49

Use BCS100 as height control unit, set IP address in machine config same in BCS100.

Details of setting IP address please check in BCS100 user manual P2.5.6.



3.7.2 Use external device as height control unit

Follower

BCS100
 BCS100 Demo
 IO

Port Configuration:

"0" means this port is not in use, it may cause logical error if you set number to those ports.

Start follow:	<input type="text" value="2"/>
Lift/Stop follow:	<input type="text" value="0"/>
Stop/Hold:	<input type="text" value="0"/>
Jog up:	<input type="text" value="0"/>
Jog down:	<input type="text" value="0"/>
Follow in place:	<input type="text" value="0"/> (Input)
Follow in place:	<input checked="" type="radio"/> Low level <input type="radio"/> High level

CypCut supports I/O control mode for height controller of other brand. User can assign output with basic functions of lift, hold, up and down etc.

Start follow: output to start follow.

Lift/stop follow: output of stop follow and lift up.

Stop/hold: output of stop follow and hold still.

Jog up: output of jog Z axis up.

Jog down: output of jog Z axis down.

Follow in place: input signal of follow reached position.

Active level (follow in place input): active level of follow in place signal.

Note: If the port number set '0', means this port not in use. If this port not assigned to any signal, doesn't set any port number, otherwise it might cause error.



3.8 Gas System

Gas

	DA	Max Pressure (Bar)
Air (L): 6	DA1	10
Oxygen (L): 7	DA1	10
Nitrogen (L): 8	DA1	10
Air (H): 0		
Oxygen (H): 0		
Nitrogen (H): 0		

Valve (L): 8

Valve (H): 0

Valve: 5

The default set of those ports above is 0, indicates that valve is not in use.
Different gas can share one proportional valve by setting the same DA port.

DA Voltage Range: 0~5V 0~10V

Control valve power suppl

DA output 0 at gas off Delay turn off valve Valve-off delay: 30s

Gas Alarm

Config alarm as needed. Any gas channel alarm doesn't affect other gas channel.

Air (L) alarm: 0	NO	Alarm (L): 0	NO
Oxygen (L) alarm: 0	NO	Alarm (L): 0	NO
Nitrogen (L) alarm: 0	NO	Alarm check delay: 0ms	
Air (H) alarm: 0	NO	Gas alarm: 0	NO
Oxygen (H) alarm: 0	NO	Alarm (H): 0	NO
Nitrogen (H) alarm: 0	NO		

Valve (H/L): master valve of high pressure or low pressure gas channel.

Air: set output for air switch.


Oxygen: set output for oxygen switch.

Nitrogen: set output for nitrogen switch.

Gas alarm: to set alarm check for each gas channel or master valve.

There are 3 DA ports of analog signal can be assigned for gas pressure regulation.

3.9 Alarm Configuration



3.9.1 Warning message

Display the warning message of yellow color when machine is running. You can edit the warning message.

3.9.2 Emergency stop button

When this signal port active will trigger emergency stop alarm.

3.9.3 Safety mode

Safety mode used for machine maintenance mode, under which machine speed and laser power will all be restricted to preset safety range.

3.9.4 Custom alarm

User can assign any input port as alarm, edit alarm description and active level of signal port, and select allowed machine actions in alarm status.

3.9.5 Allowed dual-drive error

Maximum dual-drive position error allowed, the threshold to trigger alarm.



3.10 Common input

Digit Imports

Pierce in-position check: 0


Inport function list:

Function	Input	Level Test	
Start/Continue	0	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Go Origin	0	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Laser On (Laser On When)	0	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Change To Table A	0	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Change To Table B	0	<input checked="" type="radio"/> NO	<input type="radio"/> NC
Custom Procedure 7	0	<input checked="" type="radio"/> NO	<input type="radio"/> NC

Functions


- Process control ▶ Start/Continue
- Jog ▶ Start/Pause/Continue
- Return zero/origin ▶ Cycle start
- Record/Return Record ▶ Pause
- Select Coordinate ▶ Pause+PLC+Continue
- Laser Control ▶ Continue
- Follower Control ▶ Stop
- Gas Control ▶ Breakpoint Positioning
- Output ▶ Breakpoint Continue
- Pallet Changer ▶ Frame
- Custom Procedure ▶ Dry Run

Y+
Y-

Click  button and select controlled function and active level of input signal.



3.11 Common output



3.11.1 Output configuration

Aiming: output to control guide laser.

Lasering: system will send an output signal for indicator lamp when laser in emission.

Working: system will send an output signal for indicator lamp when laser in production.

Alarm lamp: system will send an output signal for alarm lamp when alarm triggered.

Alarm bell: system will send an output signal for alarm bell when alarm triggered.

Ready: after machine axes returned origin, system will send an output.

3.11.2 Auto lubricate

After this I/O is assigned for auto lubrication, CypCut will start time/running



length counting and turn on/off lubrication when reach preset time/mileage interval.

3.11.3 Custom output

Assigned I/O will display software button under CypCut CNC tab. Custom I/O can select contact or self-lock control method.

3.11.4 Regional output

Regional output used for automatic dust extracting. When machine in production, laser head works in region A, output in region A will active and turn on dust extractor. When laser head works from region A to region B, output 12 turns off and output 15 turns on.

Turn-off delay: when laser head works from one region to another one, output of last region will turn off after preset delay.

3.12 Find Edge Setting


The screenshot shows the 'Find Edge' configuration window. It contains the following settings:

- Photo-sensor find edge
- Capacitive find edge
- output: 0
- Signal input: 0
- Switch logic: L(active when light) / D(active when light)
- Separate seeking height for pallet
- Console displays "Find edge before process"
- Disable <Find edge before process>

CypCut supports find workpiece edge by capacitance sensing and photo-electric sensor. Photo-electric sensor must be Omron E3Z-L61 model. Capacitance sensing realized by BCS100 height controller.



3.13 BCP5045 Panel



Enable BCP5045 panel in this page. In stand-alone environment, CypCut will connect to BCO5405 Mac address. In LAN environment, input ID of BCP5045. There are 12 custom buttons which can be assigned for machine function like PLC control or pallet control.



4. Electrical System Adjustment

4.1 Power Supply Checking


Connect BCL3724 I/O terminal board and BMC1214 control card by C62-pin cable, give 24V power supply to BCL3724 board. Make sure power supply in right wiring and no short circuit before power up.

Note: Do not hot plug BMC1214 card and C62-pin cable!

4.2 Basic Machine Motion Config Checking

Motor runaway risk exists in close-loop control, you need to do some checking points before first-time running.

First, confirm some basic settings in 'machine config tool' in below image: motor type, servo alarm signal polarity, pulse equivalent, encoder feedback, input gain of speed command, for dual-Y drive structure you also need to confirm rotation direction of master motor and slave motor in case of mechanic twisting (Take notice that servo drive parameters should be same settings for dual-Y axes).




Second, check motor direction and feedback pulse direction from encoder. Click

X Axis Check

open 'motor axis checking' page.


1. Click **Motor runaway check** to start motor runaway test.
2. Click **Jog(close loop)** option, then jog motor in both directions, if motor motion direction not same with command direction in CypCut, click **Reverse X** to reverse it.
3. Pulse check. This is to ensure encoder feedback pulses and input gain of speed command set right.



4.3 Hardware Signal Checking

Startup computer and open CypCut software. Open File tab > Diagnosis > IO

Monitor.




Check each signal one by one: positive limit/negative limit/origin switch of each motor axis, DA signal, PWM signal, servo enable signal and all other input and output signal.



4.4 Basic Motion Test

First, set conservative PID value in servo driver. And set conservative value of motion control parameter in CypCut. In CypCut 'Layer' > 'Global Parameter' shown as below:



Test single motor axis make sure pulse equivalent set right.

After all limit and origin signal tested to work normally, execute each motor axis return origin to build mechanical coordinate.

4.5 CypCut Basic Function Test

On CypCut control panel(right side on screen), click direction button to jog control axes, lift up/down Z axis, turn on/off gas blow, open/close aiming laser, change laser burst power etc. to test each part function well. Confirm system can control laser, BCS100 height controller, gas and other devices function well.

4.6 Position-Loop PID Self Adjustment


In CNC tab > Auto adjust, to adjust position-loop PID parameter.



The screenshot displays the FSCUT4000 Laser Cutting Control System software interface. At the top, a toolbar contains icons for 'Return Origin', 'Path', 'Balbar', 'BCS100', 'QCW', 'Auto Adjust', 'Error measure', 'Gantry Error Monitor', and 'Clean Nozzle'. The 'Auto Adjust' icon is highlighted with a red box. Below the toolbar is a horizontal scale from 0 to 100. The main window is titled 'PID Parameter Automatic adjustment' and contains a 'PID Auto Adjust' sub-window. This sub-window features a 'Rigid class' dropdown menu set to '18', a text box with instructions: 'This will move the cutting head back and forth 50mm, make sure the cutting head is in the middle of the machine.', and buttons for 'Adjustment' and 'Advanced adjustment'. Below the text are two columns of parameters for the X and Y axes. The X Axis Parameter column includes: Pid P (250), Pid TI (0.01 s), Const Differenti (3 ms), Speed Vff (0.5), integration time (0 ms), Positive compens (0 mm/s), Positive compens (0 ms), Negative comper (0 mm/s), Negative comper (0 ms), and a checkbox for '交叉耦合' (Cross-coupling) with values wP (0), wI (0 s), and wD (0 ms). The Y Axis Parameter column includes: Pid P (300), Pid TI (0.05 s), Const Differenti (3 ms), Speed Vff (0.5), integration time (0 ms), Positive compens (0 mm/s), Positive compens (0 ms), Negative comper (0 mm/s), Negative comper (0 ms), and the same '交叉耦合' checkbox with values wP (0), wI (0 s), and wD (0 ms). At the bottom of the sub-window is an 'OK(O)' button. The background of the main window shows a coordinate grid with a red horizontal line at Y=0. The bottom status bar displays 'Pause', 'Time', 'Value', 'Axis Display' (with checkboxes for 1, 2, 3, 4), 'Outline', 'Encode output: X: 5019, Y1: 14722, Y2: 14722', and 'DA Voltage X: 0, Y1: 0, Y2: 0'.



5. Adjustment Steps





6. Common Problems in Close-Loop control

6.1 Motor Runaway Error

Error source: system doesn't receive feedback pulse or receive abnormal pulses from encoder.

Checking points:

- (1) Check the wiring, make sure servo enable signal, speed command signal and encoder signal are wired with correct signal pin;
- (2) Check servo driver parameter: if set external enable, do not set deadband(neutral zone), and set zero offset value properly;
- (3) Check PID parameters in velocity loop and current loop, servo rigid level cannot be too low.

6.2 Encoder and Speed Check Failed

Error source: in Pulse Check process, program detected received encoder pulses and maximum speed doesn't match with preset value.

Checking points:

- (1) If test results remain same error value in repeated testing, check servo driver parameter if command speed gain and feedback pulses match the setting in CypCut machine config;
- (2) If test results are different error value in repeated testing, encoder signal might be disturbed. Check in electrical cabinet if separate the wiring of strong current from weak current.

6.3 Position Error Too Large

Error source: the feedback position different with command position.

Checking points:




-
- (1) Open CypCut machine config, and execute Motor runaway check make sure the checking passed;
 - (2) If this error came after increasing acceleration in CypCut, might be caused by motor torque being restricted. Driver settings restrict motor torque or motor itself is of low torque type;
 - (3) If this error came after increasing speed in CypCut, motor speed might be limited. Servo parameter might limit motor speed, or exceed motor maximum speed;
 - (4) If this type error always exist when setting acceleration and speed from high to low level, it indicates servo system is of low rigid. Mechanic or driver inner loop is low rigid.

7. Optimize Machine Motion Performance

7.1 Calculate Inertia Ratio and Preview Machine Performance Features

The inertia ratio is a crucial indicator of machine performance features. You can calculate inertia ratio of each motion axis of machine by ServoTools. Download link is <http://downloads.fscut.com/>. ServoTools interface shown below:



When inertia ratio is smaller than 200% machine runs in light load can reach high speed cutting.

When the inertia ratio is between 200% to 300% machine runs in medium load, cutting precision is declined compared with light load in high speed, cutting speed and low-pass frequency should be lower.



When inertia ratio is between 300% to 500% machine runs in heavy load and cannot reach high speed cutting.

When inertia ratio is larger than 500% indicating serious defect in machine design, servo system cannot complete adjustment in short time.

You can calculate a rough value of machine maximum cutting speed, travel speed, and acceleration by ServoTools. The calculation results can be set in CypCut > Global Parameter > Motion Control parameter. Experienced users can calculate more accurate inertia ratio by servo tuning tool.

Note: The servo parameters calculated by ServoTools only for FSCUT system of close-loop control card. Open loop control card should set servo parameter by position loop control mode.

7.2 Motion Control Parameter Adjustment

7.2.1 Motion control parameter description

Speed, acceleration, low-pass filter frequency, corner and curve precision in FSCUT4000 system are available for users to adjust, other parameters related with motion control are optimized automatically. Parameter description listed below:

Name	Description
Travel Speed	The maximum travel speed. You can calculate by ServoTools and input calculated value directly.
Travel Acceleration	The maximum travel acceleration. You can calculate by ServoTools and input calculated value directly.
Cutting Acceleration	The maximum cutting acceleration which directly influences speed in cutting curve or corner path. You need to observe the torque curve in servo tuning tool to adjust acceleration in cutting.
Low-Pass Frequency	The filter frequency to suppress machine vibration. Suppression works stronger under smaller low-pass frequency value.
Curve Precision	Curve cutting precision. Smaller value works higher curve control precision and lower speed.
Corner Precision	The precision of NURBS curve fitting corner path. Smaller value works more pointed corner cutting but also slow the speed.

7.2.2 Adjust cutting acceleration

Jog axis at high speed, 500mm/s for example, make sure axis move enough



distance to reach the pre-set speed.

Monitor the torque curve in servo tool when jog control the axis, increase the cutting acceleration if peak torque is under 80% of rated value, lower the cutting acceleration if peak torque is below 80% of rated value.


Adjust the acceleration until peak torque reaches to 80% of rated value when jog the axis in high speed. The acceleration lead screw structure can bear is usually under 0.5G. For rack gear structure is under 2G.

7.2.3 Adjust travel acceleration

You can calculate maximum travel acceleration by ServoTools. Or directly set a value 1.5~2 times larger than cutting acceleration. When machine running without load, motor peak torque should be under 150% of the rated value, and there should be no mechanism deformation or vibration under this acceleration. The acceleration lead screw structure can bear usually is under 0.5G. For rack gear structure is below 2G.

7.2.4 Adjust low pass filter frequency

You can adjust low-pass filter frequency (LPF) by cutting a part. Lower laser power and make a marking cut on workpiece. Observe the quality of marking contour. The marking graphic could be small circles in different sizes, hexagon, dodecagon, star shape and rectangle etc. As shown in the below image:



Setup low pass filter frequency as high as possible as long as not reducing



marking contour precision. The standard of contour precision should be no waving at corner position in cutting star, rectangular or polygon etc. You can setup by experiential value in below table. Setup the cutting acceleration then adjust LPF 2 levels around. The cutting acceleration has to match with LPF, you cannot setup one of them too larger than the other one.

Level	1	2	3	4	5	6	7	8	9	10
Cutting Acceleration (G)	0.1	0.2	0.3	0.4	0.5	0.6	0.8	1	1.5	2
LPF (HZ)	2	3	4	5	5.5	6	6	6	7	8

7.2.5 Curve precision and corner precision

It's recommended to use the default value. If it's really needed, you can fine tune the value a little bit around the default value.

If curve cutting precision doesn't reach requirement, you can lower the value, meanwhile cutting speed at curve also be reduced. Speed reduction is more obvious under smaller precision value. If corner cutting precision is not satisfied, you can lower the value, meanwhile cutting speed at corner also be reduced. Sharpe corner will turn to round corner under a large precision value.




8. FAQ

8.1 Cutting is Slow or Jamming

- In CypCut, open 'node mode' to view the drawing, if graphic contour made of a lot nodes, please optimize and smooth the graphic before cutting.
- Check the cutting parameter setting see if there is improper setting of time delay, or mixed time unit set 200ms to 200s for example.
- If Z axis jamming in lifting actions, check the BCS100 firmware version. If it's BCS100 V2.0, make sure firmware update to V802 and later version.
- If it takes a long time for laser to start emission, check the serial communication of laser.

8.2 Corner Over Burned

- Raise the low pass filter frequency to reduce the acceleration and deceleration time at corner.
- Raise the corner precision in global parameter to smooth the corner path.
- Modify the drawing, for example, change the corner path like below image.



- In layer parameter setting window, open speed-power regulating curve function, lower the laser power at low speed position.
- Apply cooling point technique at corner position to cool off the heated zone then resume cutting.

8.3 Laser No Emission

1. Check Laser Setting in Machine Config

- Check the laser type selection, for example, IPG YLS American version is



different with Germany version.

- If use serial or Ethernet communication, check in PC if select correct communication port.
- If use analog signal to control laser peak power, check if select right DA port.
- Check if PWM and 'Laser on' signal select right I/O port.

2. Check PWM and DA Output Signal

- In CypCut > File > Diagnosis > Card Monitor input different DA and PWM value, then measure the voltage output at DA and PWM port in BCL3724 I/O terminal board.
- If measured voltage is under pre-set value or no voltage output at all, try change another PWM or DA port then measure output voltage again.
- If it's confirmed hardware error, please contact technical support.

3. Check the Wiring

- Check the wiring of PWM, DA, serial cable and other signal wiring with laser control.
- Serial cable must have shielding layer and pin 2, 3 are crossed.

4. Check Laser Status

- Check laser status with laser software, test laser emission for trouble shooting.
- When use serial communication, it's not allowed to use multiple software to communicate with laser at same time.
- If serial communication failed, use debug mode to check command and laser response.




9. Appendix

9.1 Fly Cut Operation Guide


9.1.1 Function

There are new functions for CypCut later than V6.3.495: 'fly cut' also named 'scan line cut' in CypCut. This function applied in thin sheet cutting, used to cut arrayed parts of standard shape in high speed to improve production efficiency. Function entry shown as below.



9.1.2 Function description

Linear Fly Cut: select the rectangular array and create fly cut path. The fly cut path will be along same direction and laser head will not lift traveling between cut paths, meanwhile machine always maintain high speed in cutting.



Circular Fly Cut: select arrayed circles and create fly cut path. The cutting will follow continuous path, laser head will not lift traveling between cut paths, meanwhile machine always maintain high speed in cutting.



9.2 Pitch Error Compensation

9.2.1 Pitch error compensation description

The mechanical error in ball screw and gear rack is an absolute existence, so the actual mechanic character is different with its nominal character. For application of high precision, it requires to measure mechanical error by measuring instrument like interferometer, then offset measured data via cutting control system to reduce mechanical error.

CypCut laser cutting software designed complete compensation functions to create required machine actions for measuring device capturing data and offset error measurement data from interferometers of Renishaw, API, Agilent, OptoDyne etc. You can also set backlash error compensation directly if there is no interferometer measured data.

9.2.2 Mechanical origin

Before measure mechanical error must return axes to mechanical origin to build correct coordinate. CypCut takes origin point as reference to offset pitch error data. If the origin position is different before and after pitch error measuring, then pitch error offset cannot serve its purpose to reduce error even work in opposite effect.

Use 'Z phase' signal to improve return origin precision. FSCUT4000 system provides encoder feedback channel for each motor axis to ensure control precision.

Set return origin direction of X/Y axis by machine design. Return origin direction results in which coordinate quadrant machine runs with. If return origin towards negative direction, then machine runs in positive range of coordinate. If return origin direction towards positive direction, then machine runs in negative range of coordinate.

You can repeat return origin and measure origin precision by interferometer. The error of each origin should be no more than 5 μ m.

9.2.3 Measure pulse equivalent

The theoretical pulse equivalent is different with actual value due to mechanical



error. Precise pulse equivalent can be measured by interferometer.

Machine Params

X Axis			
Motor	Rotary	Servo Alarm	NC
Range	1,500 mm	Move	10 mm per 10,000 pulses
Encoder Pul/r	10,000	Max RPM	3,000 RPI /10V
Max Speed	500 mm/s	Max Acc	4 G
			<input type="checkbox"/> Manual
			Motor Dir: CCW
			Encoder Dir: CCW
X Axis Check			

Y Axis			
Motor	Rotary	Servo Alarm	NC
<input checked="" type="checkbox"/> Gantry		Gantry motor Dir	Diff
Range	3,000 mm	Move	10 mm per 10,000 pulses
Encoder Pul/r	10,000	Max RPM	3,000 RPI /10V
Max Speed	500 mm/s	Max Acc	4 G
			<input type="checkbox"/> Manual
			Motor Dir: CCW
			Encoder Dir: CCW
Y Axis Check			

9.2.4 Mechanic error measure

In CypCut > CNC > Path function is to setup and create motion path for interferometer to capture and record measurement data. Machine runs and pauses in preset distance and time interval, meanwhile interferometer measures and records the actual position at each pausing point. After measurement complete will generate a data table of comparison between theoretical position and actual position.

Most interferometers in market, take Renishaw for example, has to setup travel range, travel interval and time duration at each stop, like stop 1 sec every 30mm. Interferometer capturing data or not is decided by the interval distance and stop duration. First you have to setup several parameters:

Range: the range to be measured, usually a little smaller than maximum machine travel range.

Interval: by theory, shorter measure interval will get more precise offset result. Shorter measure interval will come with more stop points to be measured also take more time for a whole measurement process. Recommended interval is 10mm~100mm.

Stop time: the minimum stop duration for Renishaw is 2 seconds.




Make sure the zero point of interferometer and machine origin in same position.

Check in CypCut machine config, pitch compensation function should be disabled while still in measuring process.


9.2.5 Import measurement data to CypCut



The measurement data file can be imported in CypCut. CypCut can read measurement file generated by Renishaw, API, Agilent, OptoDyne interferometer software. If the measurement file of interferometer you are using cannot read by CypCut, please contact our technical support. Below is where to import measurement file:

Open CypCut machine config, in Machine > Pitch Compensation > Interferometer.



Click  will open below window.



Click  to import measurement file of X axis, click  to import measurement file of Y axis. Imported file will be shown in data table and graph.

If the coordinate polarity in data table is different with return origin direction, then compensation invalid.

9.2.6 The operation steps of pitch error compensation

1. Execute 'return origin' via CypCut;
2. Setup the parameter in Interferometer software;
3. Setup travel path in CypCut > CNC > Path;
4. Execute measurement program for interferometer to capture data;
5. Import measurement file to CypCut machine config;
6. Execute 'return origin' via CypCut;
7. Execute measurement program via interferometer again to check compensation result.




9.2.7 FAQ

1. Pitch error doesn't change after compensation

You need to execute return origin after import compensation file to let compensation data take effect.

If the pulse equivalent is too small, for example, less than 200 pulses per 1mm, the compensation file doesn't work.

2. Backlash larger after compensation

If backlash gap became larger or even doubled, position error data might be offset in wrong direction. Click  to switch over positive and negative data group.

This happened most likely when polarity of interferometer measure range and machine travel range not same.

3. Data curves are symmetrical

If the data curves of positive and negative direction are symmetrical in opposite direction, the polarity symbol of one of the data groups is wrong. This is rare situation, you can manually reverse the polarity symbol of positive or negative position error data group, then import file again. Or contact technical support.